

CF

SOLDER FEED STATION

Reference Guide

CF / SOLDER FEED STATION

CONTENTS


CONTROL UNIT



**SOLDER FEED IRON
AP-A**



**CABLE COLLECTOR
CC8193**



**REEL
0002801**




**FEEDING TUBE
0006559**




POWER CORD



MANUAL



MANUAL



Reference Guide	
Index	Page
English	1
Spanish	2
Dutch	13
French	17

COMPLETE STATION


CABLE COLLECTOR ASSEMBLY

1



CABLE ASSEMBLY

2



DOME RELEASE**3****METAL BRUSH**
CL6217**CABLE COLLECTOR**

Use the cable collector for keeping workplace clear of cable

**STAND****METAL BRUSH**


Use brush to clean tips and to eliminate oxidation for easy reflowing

**RUBBER BANDS**

Tap cartridge smoothly against bands to remove excess solder from tip



INSTALLATION






HEAT MANAGEMENT

JBC stations intelligently manage the tool temperature:

Work mode: When the tool is used, pre-set work temperature is 350° C.


Sleep mode: When the tool is in the stand, the temperature goes down to 220° C.

Hibernation mode: After longer periods of inactivity (pre-set i.e 30 minutes), the power is cut off and the tool cools down to room temperature.




The advantage of this heat management is lifespan increase which ensure low cost of ownership.

WORKING



SETTINGS



TECHNICAL SPECIFICATIONS

- Temperature selection from 90 to 450°C ($\pm 5\%$).
- Power: 75W.
- Safety transformer, mains separator and double isolation, with temperature protection fuse.
- **CF-2A** 230V control unit. Input: 230V 50Hz. Output: 24V.
- **CF-1A** 120V control unit. Input: 120V 60Hz. Output: 24V.
- Total weight of unit: 2,6 Kg.
- Complies with CE standards on electrical safety, electromagnetic compatibility and ESD protected housing "skin effect".
- RoHS compliant.
- Equipotential connector and the tool tip are connected to station mains ground supply for ESD protection.



This product should not be thrown in the garbage.



ENGLISH / WARRANTY

JBC's 2 years warranty guarantees this equipment against all manufacturing defects, covering the replacement of defective parts and all necessary labour.

Warranty does not cover product wear due to use or mis-use.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased enclosing this fully completed form.

SERIAL N°

STAMP OF DEALER

DATE OF PURCHASE

MORE INFORMATION
www.jbctools.com