

JTSE

Hot Air Station

Ref.: **JTSE-9B** 100V

JTSE-1B 120V

JTSE-2B 230V

SPARE PARTS

JTSE CONTROL UNIT:

-ENCLOSURES:

·TOP	0019028
·BOTTOM	0013486
·FRONT	0026199
·BACK	0021065

FOR REF. JTSE-9UA/JTSE-1UA:

-CIRCUIT	0024361
-SUCTION PUMP	0026338
-HOT AIR PUMP	0018769

FOR REF. JTSE-2UA:

-CIRCUIT	0024360
-SUCTION PUMP	0026337
-HOT AIR PUMP	0018769

Ref.: JTSE-9UA 100V	FUSE T-8A
JTSE-1UA 120V	FUSE T-8A
JTSE-2UA 230V	FUSE T-4A

