


DDST-2B 230V
DDST-1B 120V
DDST-9B 100V

SOLDERING / DESOLDERING STATION

FROM SERIE 154266

SPARE PARTS	
DD-2B / DD-1B / DD-9B:	
-CIRCUIT	0011198
-ENCLOSURES:	
· TOP	0011035
· BOTTOM	0009771
· FRONT	0010064
· BACK	0012672
MS-A:	
-CIRCUIT	0006545
-ENCLOSURES:	
· TOP	0008197
· BOTTOM	0008198
· FRONT	0008835
· BACK	0008199
-PUMP	0005652



DDST-2B 230V FUSE T-2A
 DDST-1B 120V FUSE T-4A
 DDST-9B 100V FUSE T-4A


DD-2B / DD-1B / DD-9B



DR560-A



0010207



T245-A



C245903



C245906




DR-SD



CC2056




0010211



AD-SD

0010433


0010433



MS-A



0005965



0781046




0821830



CL6217




S0354



CL9885



CL6210



0786640