

# TESE

Precision Hot Air Station

Ref.: **TESE-9B** 100V

**TESE-1B** 120V

**TESE-2B** 230V

## SPARE PARTS

### JTSE CONTROL UNIT:

#### -ENCLOSURES:

·TOP	0019028
·BOTTOM	0013486
·FRONT	0026199
·BACK	0021065


#### FOR REF. JTSE-1UA/JTSE-9UA:

-CIRCUIT	0024361
-SUCTION PUMP	0026338
-HOT AIR PUMP	0018769

#### FOR REF. JTSE-2UA:

-CIRCUIT	0024360
-SUCTION PUMP	0026337
-HOT AIR PUMP	0018769

Ref.: <b>JTSE-9UA</b> 100V	FUSE T-8A
<b>JTSE-1UA</b> 120V	FUSE T-8A
<b>JTSE-2UA</b> 230V	FUSE T-4A



ESHT

### JTSE CONTROL UNIT

