


JT-2A 230V
JT-1A 120V
JT-9A 100V

HIGH POWER HOT-AIR STATION

FROM SERIE 149165


SPARE PARTS	
JT-2A / JT-1A / JT-9A:	
-ENCLOSURES:	
-TOP	0011035
-BOTTOM	0009772
-FRONT	0004621
-BACK	0010366
-FRONT CIRCUIT	0008442
JT-2A:	
-TOP CIRCUIT	0010922
-SUCTION PUMP	0008938
-HOT AIR PUMP	0010766
JT-1A / JT-9A:	
-TOP CIRCUIT	0010930
-SUCTION PUMP	0008940
-HOT AIR PUMP	0011500

JT-2A 230V FUSE T-4A
 JT-1A 120V FUSE T-8A
 JT-9A 100V FUSE T-8A




0006368

JT-2A / JT-1A / JT-9A



JT-SA



JT-T2A (230V)
 JT-T1A (100V, 120V)



0008748