


CF-1E 120V
CF-2E 230V
CF-9E 100V
SOLDER FEED STATION



SPARE PARTS	
CF-1E / CF-2E / CF-9E:	
-CIRCUIT	0016252
-ENCLOSURE	0016248
-TOOL STAND	0014706
-SPLASHGUARD	0016953
-ANTISPLASH RUBBER	0016954

CF-1E 120V FUSE T-2A
CF-2E 230V FUSE T-1A
CF-9E 100V FUSE T-2A

