

Auto-Feed Soldering Station

Model references: AL

Displayed message	Solution
ERROR SHORTCIRCUIT	Replace the cartridge or the tool.
NO CARTRIDGE/TOOL	Replace the tool. Make sure it is compatible with the station.
ERROR WRONG TOOL	
WARNING OVERLOAD	Unit is overheat.
SYSTEM STOPPED BY OVERLOAD	Switch off and wait to cool down before new operation.
ERROR TEMP.SENSOR S	Restart the station. If not solved, contact with the Technical Service.