

JTSE-1QA 100/120V
JTSE-2QA 230V

HOT AIR STATION
 WITHOUT EXTRACTOR DESK

SPARE PARTS	
JTSE-1A / JTSE-2A:	
-ENCLOSURES:	
·TOP	0019028
·BOTTOM	0013486
·FRONT	0016862
·BACK	0021065
JTSE-1A:	
-CIRCUIT	0017185
-SUCTION PUMP	0008723
-HOT AIR PUMP	0015970
JTSE-2A:	
-CIRCUIT	0019303
-SUCTION PUMP	0008722
-HOT AIR PUMP	0015970

JTSE-1A 100/120V FUSE T-8A
 JTSE-2A 230V FUSE T-4A

