


DDSE-1A 120V
DDSE-2A 230V
DDSE-9A 100V
 REWORK STATION
 WITH ELECTRIC PUMP

DDE-1A / DDE-2A / DDE-9A



SPARE PARTS	
DDE-1A / DDE-2A / DDE-9A:	
-REAR CIRCUIT	0014997
-ENCLOSURE	
· TOP	0011035
· BOTTOM	0014567
· FRONT+DISPLAY	0014612
· BACK	0013413
MSE-A:	
-CIRCUIT	0014058
-ENCLOSURE	
· TOP	0014009
· BOTTOM	0014010
· FRONT	0014688
· BACK	0014011
-PUMP	0005652



DDSE-1A 120V FUSE T-4A
 DDSE-2A 230V FUSE T-2A
 DDSE-9A 100V FUSE T-5A

