

FS500

FUME EXTRACTOR SWITCH


Reference Guide English


FS500/FUME EXTRACTOR SWITCH

CONTAINS



INSTALLATION






ELECTRIC FUME EXTRACTOR SWITCH ELEMENTS



SETTINGS

DI 2870 station is ready by default to use the FS500. With the stations DI, DD and DM it has to be activated using the Nitrogen mode found in the "station settings" menu of the control unit.



THECNICAL SPECIFICATIONS

Supply: 24V.Power: 10W.Fuse: 5A

- Maximum power to connect 5A 250V~.
- Weight of complete unit: 450gr.
- Complies with CE standards on electrical safety, electromagnetic compatibility and ESD protected housing "skin effect".
- RoHS compliant.



This product should not be thrown in the garbage.



ENGLISH / WARRANTY

The JBC 2 years warranty, guarantees this equipment against all manufacturing defects, covering the replacement of defective parts and all necessary labour.

Warranty does not cover product wear due to use or mis-use. In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased enclosing this, fully filled in, sheet.

SERIAL N'

STAMP OF DEALER

DATE OF PURCHASE