


DIAGRAM AC 2600
VERSION 2.x



[1] Only for AD 2400 / AR 5500 / AM 6000 stations
 [2] Only for AR 5500 / AM 6000 stations
 [3] Only for °C and °F stations