

ALE Control Unit


Automatic-Feed Soldering

Ref.: **ALE-910UVA** (100V)

ALE-110UVA (120V)

ALE-210UVA (230V)

ALE CONTROL UNIT




SPARE PARTS

ALE CONTROL UNIT:

| | |
|-------------|----------------|
| -CIRCUIT | 0027663 |
| -ENCLOSURES | |
| ·LEFT | 0024365 |
| ·RIGHT | 0024366 |
| ·BACK | 0024367 |
| ·BOTTOM | 0024342 |
| -KEY SET | 0019341 |

| | | | | |
|------|------------|------|------|------|
| Ref. | ALE-910UVA | 100V | FUSE | T-2A |
| | ALE-110UVA | 120V | FUSE | T-2A |
| | ALE-210UVA | 230V | FUSE | T-1A |



GALE10V-A

(Guide Wheels and
Components already
assembled in ALE
Control Unit)