

EXTRACTORS

JBC's Hot Air stations use jointly extractors and hot air for fast and quick desoldering.

Extractors protect surrounding components by concentrating heat on the component to be desoldered.

The following models are supplied with JT and TE Hot Air stations: E2052, E2064 and E2184.

E2052 20 x 20 mm

E2064 20 x 26 mm

E2068 27 x 27 mm

E2184 24 x 24 mm

E4015 31,5 x 31,5 mm

E4020 28,5 x 28,5 mm

E2084 33 x 33 mm

E2100 38 x 38 mm

E2124 45 x 45 mm

E2190 \varnothing 7 mm



Specifications