



TESE

Precision Hot Air Station

This Plug & Play Guide corresponds to the following references:

Ref.

TESE-9B (100 V)
TESE-1B (120 V)
TESE-2B (230 V)

Station

More Information at the
product web page



Video Guide

Watch the
product video



Packing List

The following items are included according purchased station reference:



JTSE
Hot Air Control Unit 1 unit
 Ref. JTSE-9UA (100 V)
 Ref. JTSE-1UA (120 V)
 Ref. JTSE-2UA (230 V)



TES
Stand 1 unit
 Ref. TE-SF



TET
Precision Heater Hose Set 1 unit
 Ref. TE-TB (230 V / 120 V)



TN9080
TET Straight Nozzle Ø 5 mm 1 unit
 Ref. TN9080



TN9208
TET Straight Nozzle Ø 4 mm 1 unit
 Ref. TN9208



TN9209
TET Straight Nozzle Ø 3 mm 1 unit
 Ref. TN9209



PH217
Kapton Tape 1 unit
 Ref. PH217




PH218
Thermocouple Type K1 unit
 Ref. PH218



ESHT
Magazine for Protectors & Extractors 1 unit
 Ref. ESHT-A

Installation




Installation

JTSE
Power Hot Air
Control Unit

TET
Precision Heater Hose Set

PH218
Thermocouple Type K

TN
Nozzles for TET



included in
ESHT
Magazine for Protectors & Extractors



Specifications

TESE

Precision Hot Air Station

Ref. **TESE-9B** (100 V)

Ref. **TESE-1B** (120 V)

Ref. **TESE-2B** (230 V)

- Package Dimensions / Weight: 474 x 368 x 195 mm / 5.68 kg
(L x H x W) 18.7 x 14.5 x 7.68 in / 12.54 lb

Complies with CE standards.
ESD safe.

JBC

Warranty

Information regarding the warranty of each product can be found on the final page of its instruction manual.



This product should not be thrown in the garbage.

In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.