

ALE Control Unit

Automatic-Feed Soldering Control Unit With Solder Wire Perforation

Ref.:

for wire Ø 0.8mm:

- ALE-908UVB (100 V)
- ALE-108UVB (120 V)
- ALE-208UVB (230 V)

for wire Ø 1.2 mm

- ALE-912UVB (100 V)
- ALE-112UVB (120 V)
- ALE-212UVB (230 V)

for wire Ø 1.6 mm


- ALE-916UVB (100 V)
- ALE-116UVB (120 V)
- ALE-216UVB (230 V)

for wire Ø 1.0mm:

- ALE-910UVB (100 V)
- ALE-110UVB (120 V)
- ALE-210UVB (230 V)

for wire Ø 1.5 mm

- ALE-915UVB (100 V)
- ALE-115UVB (120 V)
- ALE-215UVB (230 V)



ALE CONTROL UNIT

SPARE PARTS

ALE CONTROL UNIT:

-CIRCUIT	0027663
-ENCLOSURES	
·LEFT	0024365
·RIGHT	0024366
·BACK	0024367
·BOTTOM	0024342
-KEY SET	0019341

100V	FUSE	T-2A
120V	FUSE	T-2A
230V	FUSE	T-1A

Guide Wheels and Components already assembled in ALE Control Unit

for wire Ø 0.8 mm / Ø 0.032 in

- Ref. GALE08V-B

for wire Ø 1.0 mm / Ø 0.040 in

- Ref. GALE10V-B

for wire Ø 1.2 mm / Ø 0.047 in

- Ref. GALE12V-B

for wire Ø 1.5 mm / Ø 0.059 in

- Ref. GALE15V-B

for wire Ø 1.6 mm / Ø 0.063 in

- Ref. GALE16V-B