




DSS-2B 230V
DSS-1B 120V
DSS-9B 100V


DESOLDERING STATION

FROM SERIE 152304


DI-2B / DI-1B / DI-9B



MS-A



0781046




DS360-A




0005965



CL6217



S0354



CL9885




DS-SC



CL6210

SPARE PARTS	
DI-2B / DI-1B / DI-9B:	
-CIRCUIT	0011183
-ENCLOSURES:	
· TOP	0011435
· BOTTOM	0007544
· FRONT	0009791
· BACK	0003506
MS-A:	
-CIRCUIT	0006545
-ENCLOSURES:	
· TOP	0008197
· BOTTOM	0008198
· FRONT	0008835
· BACK	0008199
-PUMP	0005652

DSS-2B 230V FUSE T-1A
 DSS-1B 120V FUSE T-2A
 DSS-9B 100V FUSE T-2,5A



0008466

0008297

0008048 (x2)

0010310 (x2)

0008042 (x2)

C360002 (x5)

C360004 (x5)

0010259

0010546

CC8200

0010433