


GSFR XX V LL-B




WITH SOLDER WIRE PERFORATION

Guide kit Ref.	Guide tube Ref.
GSFR08X03-B	0029648
GSFR08X05-B	0029649
GSFR08X06-B	0029650
GSFR08X07-B	0029651
GSFR08X10-B	0029652
GSFR10X03-B	0029653
GSFR10X05-B	0029981
GSFR10X06-B	0029654
GSFR10X07-B	0029655
GSFR10X10-B	0029656
GSFR12X03-B	0029657
GSFR12X05-B	0030647
GSFR12X10-B	0029658
GSFR15X03-B	0029659
GSFR15X04-B	0029660
GSFR15X05-B	0029661
GSFR15X10-B	0029662
GSFR15X15-B	0029663
GSFR16X03-B	0029664
GSFR16X04-B	0029665
GSFR16X15-B	0029666

Tabla general		
Wire diameter		
XX	Diameter of use	
08	Ø 0,8 mm	Ø 0,032 in
10	Ø 1,0 mm	Ø 0,040 in
12	Ø 1,2 mm	Ø 0,047 in
15	Ø 1,5 mm	Ø 0,059 in
16	Ø 1,6 mm	Ø 0,063 in

Tube length		
LL	Length	
03	0,3 m	11,81 in
04	0,4 m	15,75 in
05	0,5 m	19,69 in
06	0,6 m	23,62 in
07	0,7m	27,56 in
10	1,0 m	39,37 in
15	1,5 m	59,05 in



	Guide wheel Ref.	Blade Ref.	Blade clamp Ref.	Inlet nozzle Ref. (for SFR-A)	Interm. nozzle Ref.	Inlet nozzle Ref. (for SFR-B)	Counter wheel Ref.	Screws Ref.	Threaded stud Ref.	Needle	Metal cap	Input tube guide	
Tube length Wire ϕ													
GSFR08VLL-B	0021696	0021555	0018638	0023740	0030561	0030537	0026693 (Provide with SFR)	0026695 (x2)	0026696 (x3)	0029943	0029948	0029950	
GSFR10VLL-B	0021699			0023741	0030562	0030538				0029944			
GSFR12VLL-B	0023738			0023736	0030563	0030539				0029945			
GSFR15VLL-B	0019696			0023855	0030564	0030540	0026694			0029946		0029951	
GSFR16VLL-B	0025922			-	0030565	0030541				0029947			