


TE

Precision Hot Air Station
 Ref.: **TESE-1B** 100/120V
TESE-2B 230V


| SPARE PARTS | |
|---------------------------|---------|
| JTU CONTROL UNIT: | |
| -ENCLOSURES: | |
| ·TOP | 0019028 |
| ·BOTTOM | 0026196 |
| ·FRONT | 0026199 |
| ·BACK | 0026195 |
| FOR REF. JTSE-1UA: | |
| -CIRCUIT | 0024361 |
| -SUCTION PUMP | 0026338 |
| -HOT AIR PUMP | 0018769 |
| FOR REF. JTSE-2UA: | |
| -CIRCUIT | 0024360 |
| -SUCTION PUMP | 0026337 |
| -HOT AIR PUMP | 0018769 |

Ref.: **JTSE-1UA** 100/120V FUSE T-8A
JTSE-2UA 230V FUSE T-4A



ESHT

JTU CONTROL UNIT



TE-SF

TN9080

TN9208

TN9209

TE-B

0012374

TE-TB

PH217

PH218

