

# TE

Precision Hot Air Station Without Extractor Desk

Ref.: **TESE-1QB** 100/120V

**TESE-2QB** 230V

SPARE PARTS	
<b>JTU CONTROL UNIT</b>	
-ENCLOSURES:	
·TOP	0019028
·BOTTOM	0026196
·FRONT	0026199
·BACK	0026195
FOR REF. <b>JTSE-1UA:</b>	
-CIRCUIT	0024361
-SUCTION PUMP	0026338
-HOT AIR PUMP	0018769
FOR REF. <b>JTSE-2UA:</b>	
-CIRCUIT	0024360
-SUCTION PUMP	0026337
-HOT AIR PUMP	0018769

Ref.: **JTSE-1UA** 100/120V FUSE T-8A  
**JTSE-2UA** 230V FUSE T-4A


JTU CONTROL UNIT



PH218




TE-B



0012374

TE-TB



TN9080



TN9208



TN9209



TE-SF

