


JBC

www.jbctools.com





PCB Supports

PCB supports

PH213 PCB Support

Secure and ESD safe support for PCBs above the PH through simply placing onto adjustable support.
Dimensions: Platform 208 x 230 x 53 mm



PH215 PH Platform

Secure and ESD safe support for PCBs
above the PH
Dimensions: 280 x 380 mm

PH220 = PH215 + 4 PH214

PH210 = PH215 + 4 PH211


H010403* PC Control Panel

H101209* PC - PH updater program

(*available in web)

PH221 Magnetic PCB Support

Self-adjusting support with spring



PH212 Hand support

Height: 55.5 mm

PH211 Adjustable supports


Height adjustable magnetic support pillars
Vertical adj.: 55.5, 62.5 and 69.5 mm

PH214 Magnetic PCB Support


Magnetic support pillars
Height: 55.5 mm



PH221 Magnetic PCB Support



Hight: 55,5 to 69,5 mm



Self-adjusting support with spring



Irregular PCBs adapters



This product should not be thrown in the garbage.

JBC

WARRANTY

JBC's 2 years warranty guarantees this equipment against all manufacturing defects, covering the replacement of defective parts and all necessary labour.

Warranty does not cover product wear due to use or mis-use.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased enclosing this fully filled in, sheet.

SERIAL N°

STAMP OF DEALER

DATE OF PURCHASE

www.jbctools.com