

JBC

www.jbctools.com

English




Quick Tip Changer


Ref. S3-B

Changing the S3-B

1. Loosen the screws and slide out (max. 3mm) the sidewalls from the stand.



2. Remove the screw and place the new S3-B following the same steps conversely.




Recommendations

Make sure that the rubber does not prevent proper assembly of the walls.



When you place the new S3-B make sure the cable fits snugly and is not pinched for a proper connection.



JBC

Warranty

JBC's 2 year warranty covers this device against all manufacturing defects, including the replacement of defective parts and labour.

Warranty does not cover product wear due to use or mis-use.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage. In accordance with the European directive 2002/96/EC, electronic equipment at the end of their life must be collected and returned to an authorized recycling facility.

www.jbctools.com

0014684-0714