



## JTSE

### Power Hot Air Station without Magazine

This Plug & Play Guide corresponds to the following references:

Ref.

JTSE-9QB (100 V)  
JTSE-1QB (120 V)  
JTSE-2QB (230 V)

#### Station

More Information at the  
product web page



#### Video Guide

Watch the  
product video



## Packing List

The following items are included according purchased station reference:



### JTSE

Hot Air Control Unit ..... 1 unit  
Ref. JTSE-9UA (100 V)  
Ref. JTSE-1UA (120 V)  
Ref. JTSE-2UA (230 V)



### JTS

Stand ..... 1 unit  
Ref. JT-SF



### JTT

Heater Hose Set ..... 1 unit  
Ref. JT-T1A (100V / 120V)  
Ref. JT-T2A (230V)



### JN2015

JTT Bent Nozzle Ø 4 mm - 18 ° ..... 1 unit  
Ref. JN2015



### JN2012

JTT Bent Nozzle Ø 6 mm - 18 ° ..... 1 unit  
Ref. JN2012



### JN2020

JTT Straight Nozzle Ø 8 mm ..... 1 unit  
Ref. JN2020



### PH217


Kapton Tape ..... 1 unit  
Ref. PH217



### PH218

Thermocouple Type K .....1 unit  
Ref. PH218

# Installation



## Specifications

### JTSE

#### Power Hot Air Station without Magazine

Ref. **JTSE-9QB** (100 V) 50/60Hz. Input fuse: 8A. Rated current: 7A

Ref. **JTSE-1QB** (120 V) 50/60Hz. Input fuse: 8A. Rated current: 7A

Ref. **JTSE-2QB** (230 V) 50/60Hz. Input fuse: 4A. Rated current: 3A

- Package Dimensions / Weight: 444 x 395 x 273 mm / 6.28 kg  
(L x H x W) 17.5 x 15.6 x 10.7 in / 13.85 lb

Complies with CE standards.  
ESD safe.

# JBC

### Warranty

Information regarding the warranty of each product can be found on the final page of its instruction manual.



This product should not be thrown in the garbage.

In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.