



Steady Nano Tweezers Ref. NP105-B

Packing List

The following items should be included:

Steady Nano	Tweezers	1 unit
Ref. NP105-B		

Manual..... 1 unit Ref. 0016016





Features

Control unit Ref. NAE-18 NAE-28 NAE-98 Steady Nano Tweezers Ref. NP105-B Image: Control unit NAE-28 NAE-98 Image: Control unit Ref. NP105-B



Changing cartridges

Save time and change cartridges safely without switching the station off.

1. Removing



Place the tool in the slot and pull to remove the cartridge.

2. Inserting



Push the cartridge into the tool to the mark*.

* Important



For a proper connection insert the cartridges as far as the mark.

Aligning cartridges

Use the alignment systems to better suit the component to work.

Tip aligner



Fit the tip into the aligner and turn to the desired position.

Vertical cartridge alignment





Turn the screw of the tweezers for a vertical alignment of the cartridges. One tip lines up with the other.

Compatible cartridges

The NP105-B works with C105 cartridges. Find the model that suits your needs in www.jbctools.com



Specifications

- Weight:

- Cable length:

50 gr (0.11 lb) 120 cm (47.24 in)

Complies with CE standards ESD protected



Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labour. Warranty does not cover product wear or misuse. In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage. In accordance with the European directive 2002/96/EC, electronic equipment at the end of their life must be collected and returned to an authorized recycling facility.



Manual in other languages available on our website

www.jbctools.com