

# **JBC**

[www.jbctools.com](http://www.jbctools.com)

## **INSTRUCTION MANUAL**



## **DSH**


Heating Element

# Desoldering Iron Maintenance


**⚠ Note:** For the following operations, turn off the station or disconnect the tool and wait until the tool temperature drops to room temperature.

## Changing Heating Element


1. Remove the filter before changing the heating element.




2. Remove the fixing screw and take out the heating element.



3. Insert the new heating element into the tool.




4. Tighten the fixing screw and insert the filter.




## Changing Iron Filter


1. Remove the tube from the filter.



2. Remove the filter from the tool.



3. Insert a new filter (ref. 0008473) into the tool and mount the tube onto the filter.



# Specifications

## DSH

### Heating Element for DS360

Ref.: DSV-DS

- |   |  |
|---|--|
| - Total Net Weight:                         | 11.4 g / 0.03 lb   |
| - Package Dimensions/Weight:<br>(L x W x H) | 127 x 31 x 31 mm / 20 g<br>5.00 x 1.22 x 1.22 in / 0.04 lb |

Complies with CE standards.  
ESD safe.

# JBC

## Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labour.

Warranty does not cover product wear or misuse.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage.

In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.



[www.jbctools.com](http://www.jbctools.com)